

STEP 7:

Position the stop ring to limit the arm's range of motion if desired. The marked angle will be in the center of the range of motion.



Humanscale






STEP 8:

Insert monitor arm into the mount until release button locks in place.

To remove arm press release button and pull the arm up near the joint.



M2.1

Direct Wall Mount Installation Instructions

STEP 1: Remove the plastic front cover.

